


Introduction

The purpose of this information note is to guide you with steps to connect your Kiosk to an available Wi-Fi network in your area.

Instructions

1. Turn on the Kiosk by pressing the reset button found on the back of the device, or by plugging in the power cable to an electrical outlet. Wait until the Kiosk screen is displayed.




2. Plug in the mouse and keyboard into an available USB port on the bottom of the computer (next to the power switch or any other available USB port). In the below picture, the USB dongle from the wireless keyboard/mouse combo is used.




3. Wait until the keyboard and mouse drivers are installed. Press the escape “ESC” key on the keyboard. The screen depicted below will appear. Double click on the “View Wireless Networks” icon. Wait for 10-seconds and double-click the same icon again.




4. The “Currently connected to:” box will be displayed on the bottom right corner of the screen. If a Wi-Fi signal is not available, but the Ethernet cable is connected to the back of the device, the box will report “Network access” as per the picture below.



- If a Wi-Fi connection is available, a list of all available networks will be displayed as per below.



- Double-click on your network name. Ensure that the “Connect Automatically” box is checked.



- Enter your network security key when prompted. If a security key is not needed for your network, installation will proceed automatically.



8. Restart your Kiosk by pressing the Windows symbol on the left bottom corner of the screen and select "Shutdown" > "Restart".
9. Once the computer is rebooted, the Kiosk is connected to the Internet.
10. Verify connectivity by starting the Kiosk software – double-click on the "Kiosk" icon – and send an email to yourself after completing the full screening.